

# Application technology, 5th edition Volume III: Fonterra radiant heating and cooling





# Fonterra Side 12 Clip

# Planning

#### System description

The wall heating system Fonterra Side 12 Clip is perfectly suited for use in modern low-energy buildings, not only residential houses but also sports halls, hospitals, swimming pools etc.

The system convinces with various benefits: a reduction of the risk of accidents, no obstruction of utility spaces, and added comfort. Also for reconstruction of old buildings, Fonterra Side 12 Clip offers tried-and tested mounting options, e.g. by means of the flexible variants for installation of the system pipes.

Fonterra Side 12 Clip is a wall heating system for mounting on solid walls made of brick, concrete, sandstone etc.

The polybutene wall heating pipe is mounted on clamping rails and laid in a meandering manner. With gypsum plasters, the required plaster coverage must have a minimum thickness of 10 mm with use of reinforcement fabric to avoid cracking.

The maximum wall heating surface is 6 m<sup>2</sup> per heating circuit or 80 m including connection lines.

Depending on the selected plaster system, supply temperatures of up to 70 °C are possible. For premium comfort, however, 45 °C should not be exceeded.



Fig. 178: Installation situation Fonterra Side 12 Clip

Installation situation Fonterra Side 12 Clip



#### System features

- Can be mounted to solid walls made of brick, concrete, sandstone etc.
- Suitable as a wet system for gypsum, lime, loam, or cement plaster
- Total plaster thickness, e.g. with gypsum plasters, 26 mm
- Thanks to flexible laying options, individual room geometries can be covered without problems.
- Operating temperatures ≤ 50 °C with gypsum plasters
- Oxygen-sealed PB heating pipe acc. to DIN 4726
- Wall heating surfaces of up to 6 m<sup>2</sup> or 80 m can be connected directly to the manifold
- Safe fastening of pipes with clamping rail, in curved areas with nail round clips
- Comfortable mounting thanks to fast and flexible pipe laying
- Fonterra wall heating systems can also provide cooling
- The positions of the wall heating pipes can be identified by means of temperature foil.

### System components





Technical data system

# **Technical data**

Name	Article number
PB pipe 12x 1.3 mm, 120 mm	707712
PB pipe 12x 1.3 mm, 240 mm	615680
PB pipe 12x 1.3 mm, 650 mm	616502
PB pipe 12x 1.3 mm, in protective pipe	609658
Protective pipe for joints 12x18 mm	668945
Clamping rail 12 mm	609429
Impact dowel 35-6	615598
Nail round clips for PB 12	615611
Window screw 22 mm	625191
Pipe guide 90°	609498
connection screw fitting	614508
Connection screw fitting with SC-Contur	614584
Coupling for plastic pipe 12x1.3	614669
Press connector with SC-Contur 12x1.3 mm	614676
Plug-in piece 12x15	637002
Adapter with SC-Contur 12x1/2	636166
Temperature foil 160 x 70 mm	624910
Plaster reinforcement fabric provided on-site	on-site

Tab. 84: Technical data system

Name	Article number	<b>T</b> I.
Viega pipe shear	652005	10015
Hand press tool 12	401436	
Viega press jaw 12	425302	
Viega press tool, e.g. battery Picco	556280	

Tab. 85: Tools



#### Technical data system pipe

ŝ	System pipe			PB 12x1.3mm	
Dimensions			[mm]	12x1.3	
Minimum bending radius				5xd <sub>a</sub>	
Operating condition acc. to	ISO 10508	Class 4 Class 5	[MPa] (bar)	1 (10) 0,8 (8)	
Max. operating temperature	9		[°C]	95	
Mounting temperature			[°C]	> 5	
Water volume			[l/m]	0,069	
Heat conductivity $\lambda$			[W/(m·K)]	0,22	
Linear coefficient of length	expansion		[K <sup>-1</sup> ]	1.3 x 10 <sup>-4</sup>	
Weight			[g/m]	50	

Tab. 86: Technical data system pipe

### Wall construction



Fig. 179: Wall construction Fonterra Side 12 Clip

Fonterra Side 12 Clip can be mounted to all suitable underground types with sufficient load carrying capacity, e.g. brick walls, prefabricated and concrete walls.

The system surface facing the room transmits and distributes the heat.

#### Wall construction Fonterra Side 12 Clip



When installing a wall heating in a building, a range of structural aspects must be considered, e.g.:

- Free available wall surface
- Large areas obstructed by furniture
- Quality of the underground
- Existing installations





Fig. 180: Flexible mounting options matching the individual structural aspects

#### Notes on dimensioning

The new EnEV regulations concern wall heating systems regarding the execution of the external walls or pitched roof areas, or walls bordering on unheated rooms or soil.

If, in heated rooms, walls bordering on unheated rooms are to be replaced or installed for the first time or modified in such a way that insulation layers are provided, the maximum values specified in Appendix 3 line 5 are applicable.

Line 1	Outer walls and pitched roof areas	0.24W/(m²K)	Exc 201 Tab
Line 5a	Walls bordering on unheated rooms or soil	0.30 W/(m <sup>2</sup> K)	144

Tab. 87: Excerpt from the EnEV 2014 Appendix 3, Table 1

Subject to adherence to the above-named values, no additional heat insulation behind the wall heating must be provided. If additional insulation is required nevertheless, e.g. with internal walls against rooms with much lower inside temperatures, soft fibre timber panels can be mounted under the wall heating pipes.

External walls should be insulated only on the "cold side", i.e. the outer side of the external wall, for example by installation of upgraded insulation. In the special situation of an insulation layer at the interior-room side of the external wall, the requirements of §8 sentence 1 are considered met if the thermal transmission coefficient of the resulting wall construction does not exceed  $0.35 W/(m^2 K)$ . Interior insulation of external walls makes sense for ex-

Excerpt from EnEV 2014 Appendix 3, Fable 1



ample when refurbishing half-timbered houses, but requires particular expert knowledge, since the dew point will shift to the inside of the building, suitable vapour/moisture barriers must be installed to prevent moist inside air from getting behind the insulation layer and condensing there.

> If, generally, measures are taken during reconstruction according to EnEV § 9 sentence 1 (thermal transmission coefficient of the external building parts) and if the thickness of the insulation layer provided according to these measures is restricted for technical reasons, the requirement is considered met if the insulation layer is installed with the greatest possible thickness achievable according to the recognized state of practice (with a calculation value of the heat conductivity of 0.035 W/(m-K)).

#### System requirement

Installation data for Fonterra system	Side 12 Clip
Pipe clearance	10.0 cm
Pipes required	10 m/m <sup>2</sup>
Max. heating circuit area	6 m <sup>2</sup> or 80 m *
Mounting time in group minutes	8 to 9 min/m <sup>2</sup>

#### Tab. 88: Pipe requirement and mounting times

\* Connection lengths to the manifold must be considered.

Material required for 1.0 m <sup>2</sup>					
System components	Available quantities/packing units	Pro-rata require- ment			
PB pipe 12x1.3 mm	120/240/650m	10.00 m/m <sup>2</sup>			
Clamping rail 12 x 2000 mm	10 pieces	2.50 m/m <sup>2</sup>			
Window screws	1000 pieces	15 pc./m <sup>2</sup>			
or impact dowels	200 pieces	15 pc./m <sup>2</sup>			
Nail round clips	100 pieces	5 pc./m <sup>2</sup>			

Tab. 89: Material requirement for 1 m<sup>2</sup>

#### Pipe requirement and mounting times

Material requirement for 1 m<sup>2</sup>



#### Installation example

Viega recommends the following process for a pre-calculation:

- Select the supply temperature. Depending on the system, a supply temperature between 25 and 50 °C can be selected which is valid for the entire building. With higher supply temperatures, make sure to select a suitable plaster type.
- Calculation of the heating fluid overtemperature (see reading example output diagram).
- Dimensioning with Fonterra Side 12 Clip output diagram. Read-off of the heat output into the room. Determination of the required wall heating surface.
- Examination of the maximum heating circuit surface. Determination of the manifold outlets.
- If the total of the heating circuits or walls adds up to an excessively large heating circuit length, the heating circuit surface must be subdivided into several heating circuits.
- Calculation of the actual mass flow. Examination of the pressure losses. Calculation of the valve settings.



To ensure premium comfort, the mean heating surface temperature should not exceed 40 °C.

#### Assumptions

- Residential building: New "low-energy house"
- Heat requirement: approx. 45W/m<sup>2</sup>
- Heating system: Heat generator supply line = 42 °C, return flow = 37 °C
- Room to be dimensioned: Living room with 45m<sup>2</sup> enclosing walls surface and 25m<sup>2</sup> floor space (4.65mx5.38m) with one external wall, room height 2.75m, room temperature 20 °C
- External wall:

OHTC value =  $0.20 W/m^2 K$ , brickwork Wall surface for wall heating  $W \times H = 4.65 \times 2.75$  (2.0) m (incl. 1 window  $1.20 \times 1.0$  m) and  $5.38 \times 2.75$  (2.0) m (incl. 1 door  $1.8 m \times 2.02$  m)

Wall heating system: Fonterra Side 12 Clip



#### Sample room



Fig. 181: Sample room

### Key

- A External wall
- B Internal wall
- F Area
- H Room height (building shell dimension)
- T Room temperature

#### Calculation

- Take over the room heat requirement from the heating load calculation: Heat requirement room = 25 m<sup>2</sup>x 45 W/m<sup>2</sup> = 1125 W
- Output Side 12 Clip in W/m<sup>2</sup>: Tm = 39.5 °C minus RT 20 °C = 19.5 K (heating fluid overtemp.) acc. to diagram with 19.5 K > 110 W/m<sup>2</sup>
- Required wall heating surface: 1125 W / 110 W / m<sup>2</sup> = 10.2 m<sup>2</sup> Fonterra Side 12 Clip
- Number of heating circuits: max. 6m<sup>2</sup> per heating circuit (manifold outlet) > 2 heating circuits
- Subdivision of the wall heating surface Side 12 Clip: coverable surface external wall:
  - $B = 4.65 2 \times 0.10$  (side edge) = 4.45 m, H = 2.0

 $F=8.9-1.54 \ (window)=7.50 \ m^2 \ (required \ 10.2 \ m^2) \\ > \ difference \ 2.70 \ m^2$ 

additional covering of a further external wall

Subdivision into heating circuits of roughly the same size: 5.0 m<sup>2</sup> and 5.2 m<sup>2</sup>, possible arrangement see Fig. 182.





The arrangement of the wall heating panels shown in the illustration is only an example and must be coordinated with the building owner in respect of the furniture setup etc. In the example, the heating panels were installed at the external wall and behind the sofa to create a comfortable room climate.





Fig. 182: Potential arrangement of the required wall heating registers

# Key

- A External wall
- B Internal wall
- ① Fonterra Side 12 Clip heating circuit 1 (5 m<sup>2</sup>)
- 2 Fonterra Side 12 Clip heating circuit 2 (5.2m<sup>2</sup>)



The supply temperature of the heating installation should be set as low as possible.

This results in covering of large heating surfaces, which avoids radiation asymmetries and increases the comfort factor.



Wall view Sample room with potential heating surface covering





#### Key

Heating circuit 1
 Heating circuit 2 (continued at adjacent wall)



# Output data

Fig. 184: Output diagram Fonterra Side 12 Clip

#### Key

- A Wall,  $k = 0.35 \text{ W/m}^2$
- B Wall, k =0.50 W/m<sup>2</sup>
- 1) Heat output into the room q<sup>i</sup> in [W/m<sup>2</sup>]
- (2) Dissipation through the external wall  $q_a^*$  in [W/m<sup>2</sup>]
- (3) Heating fluid overtemperature  $\Delta \vartheta H$  in [K]

#### Output data Fonterra Side 12 Clip

= 39.5°C



Reading example - output dissipation diagram

Calculating the main heating water temperature Supply temperature + return temperature e.g.  $\frac{42^{\circ}\text{C} + 37^{\circ}\text{C}}{2}$ 

- The result is the heating fluid overtemperature e.g. 19.5 °K (value for diagram)
- Read the output q<sub>i</sub> from the diagram e.g. 110W/m<sup>2</sup> with 19.5 °K = heat dissipated into the room



Pressure loss diagram for PB pipes 12 x 1.3

Fig. 185: Pressure loss diagram for PB pipes 12 x 1.3

#### Key

1) Pressure gradient R in [Pa/m]

② Mass flow m in [kg/h] (fluid: water)

For pipes installed on external walls, take the actual losses to the outside into consideration. Next, determine the actual mass flow and R value, add the connection lines to the heating circuits, and consider them for the hydraulics.



# Mounting

### **Structural requirements**

For installing Fonterra Side 12 Clip, the following work step sequence of the various trade lots must be observed:

- Windows and doors installed
- Electrical installations (wall breaking, empty pipe installation etc.) completed
- Installation work, beamfilling etc. must be observed

Next, check that the wall installation surface is suitable for installing the system, i.e. dry, level, and firm. If all preconditions are met, installation can start.

#### **Mounting instruction**

Fastening the clamping rails

Before mounting the clamping rail, transfer the heating circuits determined in the plan to the wall surface.

The clamping rails are fastened directly on solid walls made of brick, gas concrete blocks, or concrete.

Make sure that the brickwork is free of unevenness, residual mortar etc. to allow for perfect mounting of the clamping rails and to prevent pipe damage.

#### For fastening,

- use impact dowels or window screws
- or commercially available hot-melt adhesive (start application from the centre of the clamping rail, use a hot-melt gun with at least 200 W power). Not suitable for sand-lime brick
- or a commercially available construction adhesive.



Fig. 186: Fastening the clamping rails Make sure that the clamping rails lie flat on the brickwork so that the pipelines can be fixed securely.

Fastening the clamping rails



When mounting the clamping rails, observe the clearances between the rails specified in the drawing below. For installation in pitched roof areas, it may be necessary to mount the clamping rails at smaller clearances. The clamping rails can be mounted horizontally or vertically. To allow for subsequent mounting of skirting boards, the clearance between pipes and raw floor should be 15 to 20 cm.



Viega recommends to mount the clamping rails horizontally and to fasten them with window screws or impact dowels.

Important notes on pipe laying

Observe the following when laying the pipes:

- Installation clearance of 10 cm for straight sections
- At least 12 cm in pipe sections with deflections
- Pipe protrusion in curved sections approx. 25 cm
- Fastening in curved sections by means of nail round clips
- Free laying of the wall heating pipe



Fig. 187: Installation clearance



Fig. 188: Fastening in curved sections

Important notes on pipe laying





Fig. 189: Installation diagram Key

- ① Nail round clip (brick)
- ② PB pipe 12 x 1.3
- ③ Clamping rail
- ④ Raw floor
- (5) PB pipe 12x1.3 in protective pipe

#### Connecting the technical heating elements

Checking the heating circuits

- Check the maximum wall heating surfaces of 6 m<sup>2</sup> per heating circuit (with 2 x 10 m connection line) or maximum pipe length 80 m (incl. connection line)
- The heating circuits may supply wall heating surfaces of different sizes.



If Viega press connectors are used, they are covered by the Viega warranty. After installation, mark the position of the press connectors in the plan (measure the position). The plan must be submitted to the building owner with the other documents.

#### **Connection line**

The connection lines can be laid either on the raw floor or in the screed on the heat and footfall sound insulation.



- The 12x1.3 mm pipeline is laid as a supply line from the manifold to the wall heating register (without connection to the manifold).
- Generation of the wall heating register according to the specifications
- Laying the return line up to the manifold.
- Mounting of heat insulation according to EnEV via the supply lines (supply and return flow) from the manifold to the wall heating register.
- Fastening of the pipelines on the raw floor with the appropriate pipe clamps.

#### Excerpt from the EnEV 2014 Appendix 5, Table 1

Line	Type of pipes	Minimum thickness of the insulation layer with a heat conductivity of 0.035W/mK
1	Inner diameter max. 22 mm	20 mm
2	Heat distribution lines according to lines 1-4 installed after 31 January 2002 in building parts between heated rooms of different users.	50% of the requirements of lines 1-4
7	Pipes in acc. with line 6 in the floor construction	6 mm

Requirement in the heat insulation of pipelines and fittings

Tab. 90: Requirement in the heat insulation of pipelines and fittings

For materials with other thermal conductivities, the minimum thicknesses of the insulation layers must be converted accordingly. Here, for example, a concentric insulation of 6 mm with a heat conductivity of 035 corresponds to a concentric insulation of 9 mm with a heat conductivity of 040 with 40 °C.

Table 1 does not apply if the pipes are located in heated rooms or building parts between heated rooms of one user and when the heat dissipated by such pipes can be controlled by accessible shut-off systems.

Though there are no statutory requirements, the supply lines should still be sheathed at least by a Fonterra protective pipe for joints for the following reasons:
for avoidance of knocking and flow noises,
for noise insulation,
for corrosion protection,
for reduction of heat loads

Manifold connection

Assembly steps:

- Tension-free connection of the wall heating pipe 12x1.3 mm directly to the supply or return flow or the respective manifold bar by means of Fonterra connectors
- Calibration of the flow volumes at the manifold by means of a flow quantity gauge





The combination of floor heating circuits with wall heating circuits at the manifold is also possible. The respective flow volumes can easily be set at the flow quantity gauge at the supply flow manifold.

### Flushing of the pipelines

Precondition for execution of the pressure test:

- Close the supply and return flow at the manifold as well as all supply valves
- Open the valve for heating circuit 1 and flush the heating circuit via the KFE tap at the manifold until there are no longer air bubbles in the water in the return flow line
- Close the valve for heating circuit 1 again and repeat the process for all valves
- Open the supply and return flow locks at the manifold again and do a pressure test

#### **Pressure test**

- All surface heating circuits must be checked for leak tightness by means of a water pressure test. The test pressure must be double the operating pressure, minimum 0.4 MPa (4 bar), maximum 0.6 MPa (6 bar) (see pressure test log).
- This pressure must be maintained until the end of the drywall work.
- Record leak tightness and test pressure in a test log.
- After the leakage test, re-tighten all screw fittings.



#### Caution!

It is mandatory that system components not designed for this pressure, such as expansion vessels, safety valves etc., are shut off or removed.

•

Please note that a 10K change of the pipe wall temperature occurring during the pressure test will change the test pressure by 0.05 to 0.1 bar.

#### Commissioning

After flushing the system, do the pre-setting of the heating circuit valves according to the data in the plans submitted. This is the only way for the system hydraulics to ensure proper functioning of the heating installation.

- Setting of the calculated flowthrough volumes via the valves at the manifold
- Mounting the actuators
- Setting the operating temperature



#### Anti-freeze

If there is a risk of frost, protect the system by temperature control or use of suitable anti-freeze agents (e.g. glycol). If anti-freeze is no longer required for the intended use of a system, the system must be drained and cleaned with a suitable detergent according to manufacturer's information. After that, the system can be filled again.

When using anti-freeze agents, take the increased pressure loss into consideration when doing the calculations.

# Notes on plastering

### **Requirements for plastering**

- Before starting on the plastering work, flushing and pressure testing of the wall heating system must have been completed.
- It is not necessary to heat the wall heating pipes up during plastering (exception: with loam rendering, or if specified by plaster manufacturer).
- During plastering, the wall heating system must be at operating pressure (min. 1.5 bar).

# Structural requirements

- The plaster base must be level, dry, dimensionally stable, firm, and free of contamination, efflorescence and other adhesion-inhibiting substances.
- The plasterer company must check whether measures for improving the adhesive surface must be taken.
- The room temperatures for plastering must be greater +5 °C.

# **Movement joints**

With heating surface lengths of Side 12 Clip > 10 m, movement joints must be provided on site which are usually implemented with plaster profiles. Type and arrangement must be specified by the planner.

#### Plaster construction

Generally, plastering of wall heating systems is straight-forward; the only different to regular wall plaster is the thickness of the layer and the additional reinforcement. These reinforcements prevent cracking; plasterers also use them elsewhere, for example at roller shutter boxes or window corners.



Work steps for plastering

- Plaster over the wall heating pipes and the wall clamping rails until the pipe register is covered completely (approx. 18 mm).
- Apply the reinforcement fabric (mesh width 8 to 10 mm) over the entire surface of the wall heating with approx. 20 cm overlapping at plaster opening and at unheated areas.
- Apply the cover layer (e.g. plaster "fresh-in-fresh" with gypsum plasters) so that the pipe coverage is approx. 10 mm (total thickness of plaster layer approx. 26 mm).

Furthermore, observe the relevant DIN standards, manufacturers' processing instructions, VOB (Construction Tendering and Contract Regulations), and for example the BVF datasheet "Richtlinie zur Herstellung beheizter Wand-konstruktionen im Wohnungs-, Gewerbe- und Industriebau" (Regulation on implementation of heated wall constructions in residential, commercial, and industrial buildings).

#### Suitability of various plaster types

The following plaster types are suitable for plastering wall heating systems:

- Gypsum/lime plasters up to 50 °C
- Lime/cement plasters up to 70 °C
- Loam rendering greater 50 °C

To ensure optimum heat transmission, ensure that the above-named plasters have a good heat conductivity.



Independent of the specifications / directives listed below, the plaster manufacturers' instructions must be observed.

Thermal insulation plasters are not suitable due to their poor heat conductivity. To ascertain the suitability of silicate plasters, mixed plasters, synthetic resin plasters, restoration plasters and acoustic plasters, contact the manufacturer. Observe manufacturer's installation instructions. With these plaster types, a reduction of the heating dissipation output must be expected. For the plastering work required, comply with the system manufacturer's processing instructions as well as with DIN 18550 and VOB part C DIN 18350. To achieve larger plaster thicknesses, it may be necessary to apply several layers.

For installation of plaster reinforcement, observe the wall heating or plaster system manufacturer's instructions.

Plaster reinforcements are mineral or synthetic fibre inlays in the plaster. They increase the tensile strength of the plaster and prevent widening of any cracks which may form.

#### Plasters containing gypsum/lime plasters

Due to their low shrinkage, their positive effect on the room climate and good humidity-regulating properties, these plasters are highly suitable for



use with wall heating systems. Usually applied in one layer, this plaster is suitable for operating temperatures up to 50 °C. The system is heated after complete curing of the plaster, at the earliest after 7 to 14 days (note plaster manufacturer's specifications).



With supply temperatures > 50  $^{\circ}$ C, do not use wall plaster containing gypsum.

For this temperature range, use lime/cement scales or temperature resistant special plasters.

#### Lime/cement plasters

These plasters are excellent for use as an underground for tile surfaces, e.g. in bathrooms. Usually, the plaster is applied in two layers. It is suitable for operating temperature up to 70 °C. Note the risk of shrinkage cracks. The system is heated after complete curing of the plaster, at the earliest after 21 days (note plaster manufacturer's specifications).

#### Loam rendering

Due to its diffusion permeability, high capillary conductivity, and length expansion, loam rendering is highly suitable for wall heating systems. Furthermore, loam rendering is an ideal material for biological housebuilding thanks to its numerous ecological benefits (pollutant-free, moisture absorbing, skin-friendly, heat regulating, permeable to vapour diffusion, smellabsorbing).

Usually applied in two layers, this plaster is suitable for operating temperatures > 50 °C. Optionally, jute fibre fabric can be used as reinforcement. For heat-up, comply with the plaster manufacturer's instructions.

# •

When using loam rendering on rush mats, heat-up of the wall heating after plastering is imperative to cure the rendering, because the rush mats do not absorb any moisture at all, and the rendering would not be able to dry out without heating. Furthermore, fasten a thin metal fabric over the pipe registers on the underground for better stabilisation of the pipes during the heating process; for installation in pitched roof areas, additionally fix the wall clamping rails at half the installation clearance specified above.

For loam rendering without rush mats, no special measures are required.



# Heat-up log

#### We recommend to retain the document.

Building project			Date			
Building owner's address						
Address of the qualified installa- tion company						
<ul> <li>Functional heating of plastered wall heating surfaces is intended to check the heated wall construction.</li> <li>Start of heating at the earliest</li> <li>21 days after installation of cement-bound plasters (or acc. to manufacturer's specifications)</li> <li>7 to 14 days after installation of gypsum-containing plasters (or acc. to manufacturer's specifications)</li> <li>Generally, loam rendering can be heated directly after application; compliance with the manufacturer's specifications is mandatory here as well.</li> <li>General notes</li> <li>The heating process must be slow and continuous.</li> <li>Heat for 3 days with a supply temperature of 20 to 25 °C, then 4 days with maximum design supply temperature.</li> </ul>						
Plaster manufacturer o	r type	Plastering work completed	on:			
Functional heating log						
with supp	with supply temperature 20 - 25 °C Start: End:					
with max. d	esign temp. in supply line	Start:	End:			
	Interruptions:	□ yes from:	□ no			
After functional heating, the wall heating can be switched off. After switch-off until complete cool-down, the plaster must be protected from air draughts and excessively fast cooling. Before starting the plastering work, the piping system must be set to operating pressure after undergoing a pressure test (see pressure test log).						
The system was approved for further building work at an outside temperature of °C.						
□ At this point, the wall surface were heated at a supply temperature of °C.						
Comments						
Building owner		Site management	Qualified insta	allation company		
Date/signature/stamp						



#### **Pressure test**

After completion of the installation work and execution of the pressure test, this document must be handed over to the planner/ building owner.

We recommend to retain the document.

Building project				Date	
Building owner's address					
Address of the qualified installa- tion company					
Before mounting the passi is carried out at the finishe	ve ceiling elements, the lea d but not yet covered pipel	k tightness of the l ines.	heating circuits is t	tested with water.	The leakage test
Notes on the test procedu	re				
Fill the system with fill	ered water and vent it con	npletely.			
In case of major differ	ences (~10K) between the	ambient tempera	ture and the filling	g water temperatu	re, wait for 30
minutes after filling the	e system for the temperatu	ures to adjust.			
The leakage test is do	ne with a test pressure of	min. 0.4 MPa (4 b	ar) and max. 0.6 N	/IPa (6 bar).	
Visual inspection of th	e piping system/check pe	r manometer*.			
This pressure must be	maintained until the end	of the drywall wor	k.		
Take suitable measure	es to exclude freezing, for	example room hea	ating or addition o	of anti-freeze to th	e heating water.
If the anti-freeze is not	required for normal operat	tion, the system m	ust be cleaned by	emptying and flue	shing with at least
three water exchange	S.				
The water temperature * Use pressure gauges wh	e must be kept constant d ich clearly indicate pressure	uring the test. e changes of 0.0 N	1Pa (0.1 bar).		
Materials used		Pipes	□ 12x1.3 mm		
		Pipe connectors	□ Pressing	□ Clamping	
Log of the pressure test	t				
Start of the pressure test:		Start pressure:		Water temperatu	re [°C]:
End of the pressure test:		Final pressure:		Water temperature [°C]:	
Visual inspection of pipe c	onnectors carried out?			□ yes	🗆 no
Position of couplings mark	tion of couplings marked in the installation plan?			□ yes	□ no
Leak tightness was established, no permanent form changes identified in any component?					🗆 no
Has the operating pressure been set on system handover?			□ yes	🗆 no	
Comments					
Building owner		Site manageme	ent	Qualified instal	lation company
Date/signature/stamp					



Viega Technology GmbH & Co. KG Viega Platz 1 57439 Attendorn Germany

Phone +49 (0) 2722 61-0

viega.com

INT · 709 365 · 2018-05 · VPN 170369

